

ZUMBA II

Does it all

simultaneously allows you to easily change the stream of water then the new Zumba is just the right model for you. Its flexible spout allows unrestricted use at various angles and heights, and the switch allows you to easily change the stream.



ZUMBAII -



Standing sink mixer

flexible spout black colour

BZA42B



Standing sink mixer

flexible spout beige colour

BZA42P



Standing sink mixer

flexible spout silver colour

BZA42S



Standing sink mixer

flexible spout yellow colour

BZA42C



Standing sink mixer

flexible spout green colour

BZA42G



Standing sink mixer

flexible spout white colour

BZA42W



Standing sink mixer

flexible spout mint colour

BZA42M



Standing sink mixer

flexible spout red colour

BZA42R

Two


streams

Zumba II is equipped with a stream switch with two functions: aeration and spray. The jet is changed by rotating the spout tip.



▼ Aerated stream

Uniform gentle stream in the middle of the tip. Used to fill dishes.



▼ Spray

The stream is dispersed through nozzles located within the perimeter of the spout. Practical for hand washing and rinsing fruits and vegetables.



Flexible spout

Extremely useful function for those who appreciate the smooth and comfortable handling of a faucet. It allows you to give the spout any shape, change height and range of the water jet as required, for fast rinsing of dishes or comfortable washing of the sink.

A combination of two types of jet with a flexible spout provides optimum comfort during washing up.





